

### MAINTENANCE SCHEDULE - EUROPE 10,000 km/6,000 miles

| Gasoline engine                                                                                                                                                                                                                                                                                                                                                                                         |  |  |                                                                                 |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        |                                          |                                          |             |                                                   |  |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|--|---------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--------|------------------------------------------|------------------------------------------|-------------|---------------------------------------------------|--|
| MAINTENANCE OPERATIONS<br>I: Inspect and correct or replace as necessary.<br>R: Replace or change or lubricate.      T: Tighten to specified torque.                                                                                                                                                                                                                                                    |  |  |                                                                                 |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        |                                          |                                          |             |                                                   |  |
| SERVICE INTERVALS:<br>Odometer reading or months, whichever comes first                                                                                                                                                                                                                                                                                                                                 |  |  | ODOMETER READING                                                                |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  | Months | Starting Year/Month of Production        | Model Code                               | Engine Code | Yaris GR<br>G16E-GTS<br>(1.6 Turbo)<br><br>GXPA16 |  |
|                                                                                                                                                                                                                                                                                                                                                                                                         |  |  |                                                                                 |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        |                                          |                                          |             |                                                   |  |
|                                                                                                                                                                                                                                                                                                                                                                                                         |  |  |                                                                                 |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        |                                          |                                          |             |                                                   |  |
| MAINTENANCE ITEMS                                                                                                                                                                                                                                                                                                                                                                                       |  |  |                                                                                 |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        |                                          |                                          |             |                                                   |  |
| Floor mat                                                                                                                                                                                                                                                                                                                                                                                               |  |  | Inspection at every maintenance                                                 |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | -                                        |                                          |             |                                                   |  |
| Body Inspection                                                                                                                                                                                                                                                                                                                                                                                         |  |  |                                                                                 |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 24 months                          |                                          |             |                                                   |  |
| Drive belts                                                                                                                                                                                                                                                                                                                                                                                             |  |  | Inspect every 20,000 km (12,000 miles). Replace every 100,000 km (60,000 miles) |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | -                                        |                                          |             |                                                   |  |
| Engine oil                                                                                                                                                                                                                                                                                                                                                                                              |  |  | Normal                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 12 months                          |                                          |             |                                                   |  |
|                                                                                                                                                                                                                                                                                                                                                                                                         |  |  | Severe                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 6 months                           |                                          |             |                                                   |  |
| Engine oil filter                                                                                                                                                                                                                                                                                                                                                                                       |  |  | Normal                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 12 months                          |                                          |             |                                                   |  |
|                                                                                                                                                                                                                                                                                                                                                                                                         |  |  | Severe                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 6 months                           |                                          |             |                                                   |  |
| Cooling and heater system *2                                                                                                                                                                                                                                                                                                                                                                            |  |  |                                                                                 |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 24 months                          |                                          |             |                                                   |  |
| Engine coolant<br>(including intercooler coolant)                                                                                                                                                                                                                                                                                                                                                       |  |  | Inspect                                                                         |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | -                                        |                                          |             |                                                   |  |
|                                                                                                                                                                                                                                                                                                                                                                                                         |  |  | Replace                                                                         | First replace at 160,000 km (96,000 miles), then replace every 80,000 km (48,000 miles)               |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        |                                          | -                                        |             |                                                   |  |
| Exhaust pipes and mountings                                                                                                                                                                                                                                                                                                                                                                             |  |  |                                                                                 |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 12 months                          |                                          |             |                                                   |  |
| Spark plugs                                                                                                                                                                                                                                                                                                                                                                                             |  |  | Repac every 100,000 km (60,000 miles)                                           |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | -                                        |                                          |             |                                                   |  |
| Battery (12V)                                                                                                                                                                                                                                                                                                                                                                                           |  |  |                                                                                 |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 12 months                          |                                          |             |                                                   |  |
| Fuel filter *3                                                                                                                                                                                                                                                                                                                                                                                          |  |  |                                                                                 |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 96 months                          |                                          |             |                                                   |  |
| Fuel injection system *4                                                                                                                                                                                                                                                                                                                                                                                |  |  | Add injector cleaner to fuel tank every 10,000 km (6,000miles)                  |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | -                                        |                                          |             | *                                                 |  |
| Air cleaner filter (including checking pre-air cleaner if equipped)                                                                                                                                                                                                                                                                                                                                     |  |  | Paper type or Non-woven fabric type                                             | Normal                                                                                                |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        |                                          | I: Every 24 months<br>R: Every 48 months |             |                                                   |  |
|                                                                                                                                                                                                                                                                                                                                                                                                         |  |  | Dusty road *1                                                                   | Inspect every 2,500 km (1,500 miles) or 3 months. Replace every 40,000 km (24,000 miles) or 48 months |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        |                                          |                                          |             |                                                   |  |
| Fuel tank cap, fuel lines, connections and fuel vapor control valve*2                                                                                                                                                                                                                                                                                                                                   |  |  |                                                                                 |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 24 months                          |                                          |             |                                                   |  |
| Charcoal canistar                                                                                                                                                                                                                                                                                                                                                                                       |  |  |                                                                                 |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 24 months                          |                                          |             |                                                   |  |
| Clutch pedal                                                                                                                                                                                                                                                                                                                                                                                            |  |  | No maintenance                                                                  |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | -                                        |                                          |             |                                                   |  |
| Brake pedal and parking brake                                                                                                                                                                                                                                                                                                                                                                           |  |  |                                                                                 |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 6 months                           |                                          |             |                                                   |  |
| Brake linings and drums<br>(Include brake linings and drums of parking brake)                                                                                                                                                                                                                                                                                                                           |  |  | Normal                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 12 months                          |                                          |             |                                                   |  |
|                                                                                                                                                                                                                                                                                                                                                                                                         |  |  | Severe                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 6 months                           |                                          |             |                                                   |  |
| Brake pads and discs                                                                                                                                                                                                                                                                                                                                                                                    |  |  | Normal                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 6 months                           |                                          |             |                                                   |  |
|                                                                                                                                                                                                                                                                                                                                                                                                         |  |  | Severe                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 3 months                           |                                          |             |                                                   |  |
| Brake fluid                                                                                                                                                                                                                                                                                                                                                                                             |  |  |                                                                                 |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | I: Every 6 months<br>R: Every 24 months  |                                          |             |                                                   |  |
| Clutch fluid                                                                                                                                                                                                                                                                                                                                                                                            |  |  |                                                                                 |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | I: Every 6 months<br>R: Every 24 months  |                                          |             |                                                   |  |
| Brake pipes and hoses                                                                                                                                                                                                                                                                                                                                                                                   |  |  | Normal                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 12 months                          |                                          |             |                                                   |  |
|                                                                                                                                                                                                                                                                                                                                                                                                         |  |  | Severe                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 6 months                           |                                          |             |                                                   |  |
| Vacuum pump for brake booster                                                                                                                                                                                                                                                                                                                                                                           |  |  | Inspect every 200,000 km (120,000 miles)                                        |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | -                                        |                                          |             | **                                                |  |
| Steering wheel, linkage and steering gear box                                                                                                                                                                                                                                                                                                                                                           |  |  | Normal                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 12 months                          |                                          |             |                                                   |  |
|                                                                                                                                                                                                                                                                                                                                                                                                         |  |  | Severe                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 3 months                           |                                          |             |                                                   |  |
| Propeller shaft bolts                                                                                                                                                                                                                                                                                                                                                                                   |  |  | Normal                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 12 months                          |                                          |             |                                                   |  |
|                                                                                                                                                                                                                                                                                                                                                                                                         |  |  | Severe                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 6 months                           |                                          |             |                                                   |  |
| Drive shaft boots                                                                                                                                                                                                                                                                                                                                                                                       |  |  | Normal                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 24 months                          |                                          |             |                                                   |  |
|                                                                                                                                                                                                                                                                                                                                                                                                         |  |  | Severe                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 12 months                          |                                          |             |                                                   |  |
| Suspension ball joints and dust covers                                                                                                                                                                                                                                                                                                                                                                  |  |  | Normal                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 12 months                          |                                          |             |                                                   |  |
|                                                                                                                                                                                                                                                                                                                                                                                                         |  |  | Severe                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 6 months                           |                                          |             |                                                   |  |
| Shift lever for manual transmission                                                                                                                                                                                                                                                                                                                                                                     |  |  |                                                                                 |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | -                                        |                                          |             |                                                   |  |
| Manual transmission oil                                                                                                                                                                                                                                                                                                                                                                                 |  |  | Normal                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 48 months                          |                                          |             |                                                   |  |
|                                                                                                                                                                                                                                                                                                                                                                                                         |  |  | Severe                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 48 months                          |                                          |             |                                                   |  |
| Transfer oil                                                                                                                                                                                                                                                                                                                                                                                            |  |  | Normal                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | I: Every 12 months<br>R: Every 48 months |                                          |             |                                                   |  |
|                                                                                                                                                                                                                                                                                                                                                                                                         |  |  | Severe                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 24 months                          |                                          |             |                                                   |  |
| Front differential oil                                                                                                                                                                                                                                                                                                                                                                                  |  |  | Normal                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 48 months                          |                                          |             |                                                   |  |
|                                                                                                                                                                                                                                                                                                                                                                                                         |  |  | Severe                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 48 months                          |                                          |             |                                                   |  |
| Rear differential oil                                                                                                                                                                                                                                                                                                                                                                                   |  |  | Normal                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | I: Every 12 months<br>R: Every 48 months |                                          |             |                                                   |  |
|                                                                                                                                                                                                                                                                                                                                                                                                         |  |  | Severe                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 48 months                          |                                          |             |                                                   |  |
| Front and rear suspension                                                                                                                                                                                                                                                                                                                                                                               |  |  | Normal                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 12 months                          |                                          |             |                                                   |  |
|                                                                                                                                                                                                                                                                                                                                                                                                         |  |  | Severe                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 6 months                           |                                          |             |                                                   |  |
| Bolts and nuts on chassis and body *5                                                                                                                                                                                                                                                                                                                                                                   |  |  | Severe only                                                                     |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 6 months                           |                                          |             |                                                   |  |
| Tires and inflation pressure                                                                                                                                                                                                                                                                                                                                                                            |  |  |                                                                                 |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 6 months                           |                                          |             |                                                   |  |
| Lights, horns, wipers and washers                                                                                                                                                                                                                                                                                                                                                                       |  |  |                                                                                 |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | Every 6 months                           |                                          |             |                                                   |  |
| Air conditioner filter                                                                                                                                                                                                                                                                                                                                                                                  |  |  | Particle filter (Pollen removal type)                                           | Normal                                                                                                |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        |                                          | -                                        |             |                                                   |  |
|                                                                                                                                                                                                                                                                                                                                                                                                         |  |  | Severe                                                                          |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        | -                                        |                                          |             |                                                   |  |
| *1: Roads in areas where their pavement rate is low, or a cloud of dust arises and the air is dry.<br>*2: After 80,000km (48,000miles) or 48 months inspection, inspect every 20,000km (12,000miles) or 12 months<br>*3: Including the filter in fuel tank.<br>*4: Toyota genuine fuel injector cleaner or equivalent<br>*5: For seat mounting bolts, front and rear suspension member retaining bolts. |  |  |                                                                                 |                                                                                                       |  |  |  |  |  |  |  |  |  |  |  |  |  |  |        |                                          |                                          |             |                                                   |  |

<